



Simple to Start:




1. Press the ON Key.
2. The THERMO KING Logo appears briefly.
3. The startup screen appears while communications are established and the unit prepares for operation.





4. The Standard Display defaults to the "TemperatureWatch" screen after 2 1/2 minutes. (Three Zone shown.) The TemperatureWatch Display will remain on until any key is pressed or a check, prevent or shutdown alarm occurs and will show the return air temperature and setpoint for each zone.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Set: CYCLE-SENTRY or Continuous Mode





1. Return to the Standard Display.
2. Press the CYCLE-SENTRY/Continuous Key.
3. The "Programming Continuous Mode" or "Programming CYCLE-SENTRY Mode" screen briefly appears.
4. The "New System Mode is Continuous" screen or the "New System Mode CYCLE-SENTRY" screen briefly appears.
5. The Standard Display appears and the heading on top of screen reads the new mode.



6. Pressing the CYCLE-SENTRY/Continuous Key again will change the unit back to the previous mode.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.



Simple to Set: Setpoint Temperature



1. Press any soft key to return to the Standard Display. Press the appropriate ZONE Key on the Standard Display.
2. Press the + or - Keys to change the setpoint reading.
3. Press the YES or NO Key accordingly.
4. The Standard Display appears with setpoint changed to the new setpoint.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Check: Gauges





1. Return to the Standard Display. Press the MENU Key.
2. Use UP and DOWN soft keys to scroll to the gauges option. Press the SELECT Key when gauges option is highlighted.

3. Press BACK or NEXT Keys to scroll through following gauges: Coolant Temperature, Coolant Level, Engine Oil Pressure, Engine Oil Level, Amps, Battery Voltage, Engine RPM, Fuel Level Sensor, Discharge Pressure, Suction Pressure, ETV Position, I/O (Input/Output State). If no keys are pressed within 30 seconds, the screen will return to the Standard Display.

4. Press the LOCK Key to display any gauge screen for an indefinite period. Press the key again to unlock the screen.
5. Press the EXIT Key to return to the Standard Display.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.




Simple to Defrost: Initiate Manual Defrost



1. In Standard Display, press the DEFROST Key.
2. Select Zone to defrost.
3. Display briefly shows [DEFROST], [PROGRAMMING DEFROST - PLEASE WAIT] and then [DEFROST STARTED].
4. Display shows the Defrost Display. The bar indicator shows approximate defrost time remaining.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Access: Sensors





1. Return to the Standard Display. Press the MENU Key.
2. Use UP and DOWN soft keys to scroll to the sensors option. Press the SELECT Key when sensors option is highlighted.

3. Press the BACK or NEXT Keys to scroll through the sensor screens for each Zone: Return Air Temperature, Discharge Air Temperature and Temperature Differential. Continue scrolling to see Ambient Air Temperature, Spare Sensors 1-3, Datalogger Temperature Sensors 1-6 and the Board Temperature Sensor. If no keys are pressed within 30 seconds, the screen will return to the Standard Display.

4. Press the LOCK Key to display any sensor screen for an indefinite period. Press the key again to unlock the screen.
5. Press the EXIT Key to return to the Standard Display.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Test: Pretrip Test





1. Clear all alarm codes. (See "Simple to Clear" on other side of this pocket card.)
2. Return to the Standard Display.
3. Press the MENU Key.
4. Press the UP or DOWN Key to choose the Pretrip Menu.
5. Press the SELECT Key to start a Pretrip Test.
6. If the unit is not running, a Full Pretrip will be initiated. If the unit is running in either diesel or electric mode, a Running Pretrip will be performed.

7. When all tests are complete, the results are reported as PASS, CHECK or FAIL. If the results are CHECK or FAIL, the accompanying alarm codes will direct the technician to the cause of the problem.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Check: Hourmeters







1. Return to the Standard Display screen.
2. Press the MENU Key.
3. Use UP and DOWN soft keys to scroll to the Hourmeters option.
4. Press the SELECT Key when Hourmeters option is highlighted.

5. Press the NEXT and BACK Keys to view the Hourmeter Displays.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.



Simple to View: Cause of Alarm



1. Return to the Standard Display Screen.
2. Press the MENU Key.
3. Press the UP or DOWN soft keys to scroll to the Alarm option.
4. Press the SELECT Key when Alarms Option is highlighted.
5. If alarms are present, the quantity of alarms and the most recent alarm code number will be shown.
6. If necessary to view all alarms, scroll down using the DOWN Key.
7. If a serious condition occurs, the unit will be shut down to prevent damage to the unit or the load. If this occurs, the display and backlight will flash on and off.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Clear: Clearing Alarm Codes




1. If the alarm situation has been resolved press the CLEAR Key to clear the alarm.
2. The display will briefly show CLEARING ALARMS – PLEASE WAIT. Then the Alarm Menu will reappear.
3. Press the HELP Key for additional information regarding the alarm shown on the display. Also see the complete Alarm Code list in the next column.
4. To return to the Alarms Menu press the EXIT Key. To return to the Standard display press the EXIT Key again.

NOTE: For more detailed information, see the Operation chapter in the appropriate unit operating manual.

Simple to Determine: Cause of Alarm

- | | |
|-----|--|
| 0 | No Alarms Exist |
| 2 | Check Evaporator Coil Sensor (Zone) |
| 3 | Check Return Air Sensor (Zone) |
| 4 | Check Discharge Air Sensor (Zone) |
| 5 | Check Ambient Air Sensor |
| 6 | Check Coolant Temp Sensor (Engine Only) |
| 7 | Check Engine RPM Sensor (Engine Only) |
| 9 | High Evaporator Temperature (Zone) |
| 10 | High Discharge Pressure |
| 11 | Unit Controlling Alternate Sensor (Zone) |
| 12 | Sensor Shutdown (Zone) |
| 13 | Sensor Calibration Check (Zone) |
| 17 | Engine Failed to Crank (Engine Only) |
| 18 | High Engine Coolant Temperature |
| 19 | Low Engine Oil Pressure |
| 20 | Engine Failed to Start |
| 21 | Cooling Cycle Check (Zone) |
| 22 | Heating Cycle Check (Zone) |
| 23 | Cooling Cycle Fault (Zone) |
| 24 | Heating Cycle Fault (Zone) |
| 25 | Alternator or Battery Charger Check |
| 26 | Check Refrigeration Capacity (Zone) |
| 28 | Pretrip Abort |
| 29 | Check Defrost Damper Circuit |
| 30 | Defrost Damper Stuck |
| 31 | Check Oil Pressure Switch |
| 32 | Refrigeration Capacity Low (Zone) |
| 33 | Check Engine RPM |
| 35 | Check Run Relay Circuit |
| 36 | Electric Motor Failed to Run |
| 37 | Check Engine Coolant Level |
| 38 | Electric Phase Reversed |
| 39 | Check Water Valve Circuit |
| 40 | Check High Speed Circuit |
| 42 | Unit Forced to Low Speed |
| 44 | Check Fuel System |
| 45 | Check Hot Gas Bypass Circuit |
| 46 | Check Air Flow |
| 48 | Check Belts or Clutch |
| 49 | Check Spare Sensor 1 |
| 50 | Reset Clock |
| 52 | Check Heat Circuit |
| 53 | Check Liquid Line Solenoid or Economizer Valve |
| 54 | Test Mode Timeout |
| 56 | Check Host Evaporator Blower Low Speed |
| 57 | Check Host Evaporator Blower High Speed |
| 61 | Low Battery Voltage |
| 62 | Ammeter Out of Calibration |
| 63 | Engine Stopped |
| 64 | Pretrip Reminder |
| 65 | Abnormal Temperature Differential (Zone) |
| 66 | Low Engine Oil Level |
| 67 | Check Liquid Line Solenoid Circuit |
| 68 | Internal Controller Fault Code |
| 70 | Hourmeter Failure |
| 74 | Controller Reset to Defaults |
| 79 | Internal Data Logger Overflow |
| 80 | Check Comp Temp Sensor |
| 82 | High Comp Temp Shutdown |
| 83 | Low Engine Coolant Temperature |
| 84 | Restart Null |
| 85 | Forced Unit Operation |
| 86 | Check Discharge Pressure Sensor |
| 87 | Check Suction Pressure Sensor |
| 89 | Check Electronic Throttling Valve Circuit |
| 90 | Electric Overload |
| 91 | Check Electric Ready Input |
| 92 | Sensor Grades Not Set (Zone) |
| 93 | Low Compressor Suction Pressure |
| 96 | Low Fuel Level |
| 96 | Low Fuel Level |
| 98 | Check Fuel Level Sensor |
| 99 | High Compressor Pressure Ratio |
| 105 | Check Receiver Tank Pressure Solenoid Circuit |
| 106 | Check Purge Valve Circuit |
| 107 | Check Condenser Inlet Solenoid Circuit |
| 108 | Door Open Timeout (Zone) |
| 110 | Check Suction Line Solenoid Circuit |
| 111 | Unit Not Configured Correctly (Zone) |
| 112 | Check Remote Fans (Zone) |
| 113 | Check Electric Heat Circuit (Zone) |
| 114 | Multiple Alarms - Can Not Run |
| 117 | Auto Switch from Diesel to Electric |
| 118 | Auto Switch from Electric to Diesel |
| 120 | Check Alternator Excite Circuit |
| 121 | Check PWM Liquid Injection Circuit |
| 122 | Check Diesel/Electric Circuit |
| 127 | Setpoint Not Entered (Zone) |
| 128 | Engine Run Time Maintenance Reminder #1 |
| 129 | Engine Run Time Maintenance Reminder #2 |
| 130 | Electric Run Time Maintenance Reminder #1 |
| 131 | Electric Run Time Maintenance Reminder #2 |
| 132 | Total Unit Run Time Maintenance Reminder #1 |
| 133 | Total Unit Run Time Maintenance Reminder #2 |
| 134 | Controller Power On Hours |
| 141 | Auto-switch Diesel to Electric Disabled |
| 143 | Check Remote Zone Drain Hose Heater Output |
| 144 | Lost Expansion Module CAN Communication |
| 145 | Loss of Controller On Feedback Signal |
| 146 | Software Version Mismatch |
| 148 | Autoswitch Electric to Diesel Disabled |
| 150 | CargoWatch Sensor Out of Range Low (Zone) |
| 151 | CargoWatch Sensor Out of Range High (Zone) |
| 152 | CargoWatch Sensor Failed (Zone) |
| 153 | Expansion Module Flash Load Failure |
| 157 | OptiSet File Mismatch |
| 158 | Primary Software Failed to Load |
| 159 | Check Battery Condition |
| 160 | Lost Radio Expansion Board CAN Comm. |
| 203 | Check Display Return Air Sensor (Zone) |
| 204 | Check Display Discharge Air Sensor |
| 233 | REB Transitioning - Conservative to Full Null |
| 234 | Check Relative Humidity Sensor Circuit |
| 251 | REB Miss-configured |
| 252 | Check Auto Fresh Air Exchange Door Circuit |
| 500 | Check Host Evaporator Blower Low Speed |
| 501 | Check Host Evaporator Blower High Speed |
| 505 | Check Roadside Cond. Fan Motor Speed Circuit |
| 506 | Check Curbside Cond. Fan Motor Speed Circuit |
| 507 | Check Digital Scroll Output Circuit |
| 508 | Speed Request Communication Error |
| 509 | Engine Control Unit (ECU) Failed to Enable |
| 510 | Engine Control Unit (ECU) Run Signal Failed |
| 511 | Engine Wait to Start Time Delay Expired |
| 512 | High Compressor Suction Pressure |
| 513 | Low Compressor Suction Ratio |
| 514 | Low Compressor Discharge Pressure |
| 515 | Minimum ETV Discharge Superheat Temp |
| 516 | I/O Controller to Application Controller Com Failure |
| 518 | Generator Ground Fault |
| 519 | Battery Charger Input Voltage Out of Range |
| 520 | Battery Charger Output Fault |
| 521 | Battery Charger Overheat Shutdown |
| 522 | Check Battery Temperature Sensor |
| 523 | Unit Battery Exceeded High Temp. Limit |
| 524 | Generator Operational Limit V out to Frequency Ratio |
| 525 | Generator Frequency Range Fault |
| 526 | Generator Operational Limit Output Current |
| 528 | Failed J1939 CAN Communication Base Controller/Battery Charger |
| 529 | Check Fuel Pump Circuit |
| 530 | Low Pressure Differential |
| 531 | Check Economizer Pressure Sensor |
| 538 | Engine J1939 CAN Datalink Degraded |
| 539 | Engine J1939 CAN Datalink Failed |
| 540 | Illegal Engine Operating State |
| 542 | Battery Charger Fault - Unit Forced to Low Speed |
| 543 | Battery Charger Internal Short |
| 544 | Battery Charger External Short |
| 545 | Battery Charger Output Voltage Exceeded Limit |
| 546 | Battery Charger Operating Bulk Voltage Out of Range |
| 547 | AC Bus Phase Loss |
| 548 | Battery Charger Temp Below Op. Range |
| 549 | Battery Charger AC Input Overvoltage |
| 550 | Battery Charger Internal Overvoltage Fault |
| 551 | Battery Charger Internal temp Sensor Fault |
| 552 | Battery Charger Charging - Low Battery |
| 553 | Battery Charger Operating Derated Due to High Temp |
| 599 | Engine Service Tool Connected |
| 800 | Crankshaft Position Sensor Error |
| 801 | Camshaft Position Sensor Error |
| 804 | Engine Coolant Temperature Sensor Error |
| 807 | Fuel Temperature Sensor Error |
| 808 | Rail Pressure Sensor Error |
| 809 | Intake Air Pressure Sensor Error |
| 810 | Atmospheric Pressure Sensor Error |
| 811 | Glow Plug Circuit Error |
| 813 | General Injector Error |
| 815 | Fuel Pressure Regulator Error |
| 818 | EGR Valve Actuator Error |
| 819 | ECU Power Relay Error |
| 820 | Main ECU Relay Error |
| 825 | T1 Air Intake Temperature Sensor Error |
| 826 | T2 Air Intake Temperature Sensor Error |
| 827 | EGR Valve Position Sensor Error |
| 828 | Lambda System Error |
| 829 | Engine Communication Error |
| 830 | Air Flow Meter Error |
| 832 | Engine Sensor Power Supply Error |
| 833 | High Pressure Pump Fuel Metering Unit Error |
| 834 | Water in Fuel Sensor Error |
| 836 | Major ECU Failures |
| 838 | Intake Error System Error |
| 839 | Engine Speed Error |
| 840 | Fuel Injection Energizing Error |
| 841 | High Pressure Pump Wear |
| 842 | Engine Running in Safe Mode - Low Speed |
| 843 | Fuel Injection System Error |
| 844 | Failed to Crank |
| 845 | Starter Relay Error |
| 846 | T50 Switch Error |
| 847 | Variant Coding Error |
| 853 | Engine Overspeed (No DTC) |
| 854 | ECU Self Commanded Shutdown |
| 899 | Unknown ECU Fault |

SR-4 MT Smart Reefer™ 4 Microprocessor



Driver Guide to Simple Operation



TK 55870-2-PC (Rev. 0, 01/14)

©Thermo King Corporation